



Application of **XL-08** Corten /steel rust accelerator

Please read the safety data and use recommended PPE instructed on the label.

Avoid contact with skin and eyes wear protective gloves and eyewear!

May cause temporary skin bleaching. This will pass in approx. 30 mins!

Application

- Step1 Prepare surface to remove any protective oil or films with soapy water using cloth or scouring pad.
Various finishes may be achieved by different surface preparations such as, sandblast, grinding or sanding the surface prior to application of the **XL-08** solution.
- Step2 Apply **XL-08** via a hand pump spray, trigger spray or similar. Ensure that all surfaces are saturated. Note The position of the surface being treated will effect the patination such as horizontal or verticle
- Step3 Leave to dwell. The XL-08 will start reacting within 2 to 3 minutes. **The XL-08** will foam and bubble.
- Step4 DO NOT ALLOW TO DRY. Keep wet using a saltwater solution via pump spray.
Keep checking the level of patina until desired level is achieved.
- Step5 Rinse thoroughly with fresh clean water to reveal the finish. If not satisfied the level of patina, then repeat application of **XL-08** from **step 2**.

Neutralisation

IMPORTANT

Rinse and wash down with **BROMOCO ERW-BD** solution ensuring that all reveals and folds are treated.

No need to scrub or brush allow to dwell for 5 minutes.

Fully rinse of **ERW-BD** with fresh running water

Allow to dry thoroughly and completely prior to application of **BROMOCO CT7571T**